

## Installation Instructions: PART# 7100

### Stone Guards, 1966-77 Bronco

#### Contents:

- 1 Stone Guard, Left
- 1 Stone Guard, Right
- 20 Self Tapping Screws

#### Tools Needed:

1/4" drive ratchet, extension and 5/16" socket.  
Drill with a 90° angled head attachment and an 1/16" drill bit.  
Contrasting Sharpie color marker. Black for light vehicles and Metallic Silver for dark vehicles works best.

#### Please read completely before beginning.

1. Slightly bend and insert each Fender Stone guard in place as shown. Edges of the guard should match the seam edge inside the fender.
2. While firmly holding panel in place, mark the hole locations with the Sharpie marker.
3. Remove Fender Stone Guard and drill 1/16" pilot holes for the self-tapping screws. (Damage may occur if Stone Guard is left in place during this step!)
4. Re-install Stone Guard. Then, using the 1/4" ratchet and socket, install all self-tapping screws securely. (Caution: over tightening may cause threads to strip.)



865-938-6696 m-f eastern  
3231 NW Park Dr Knoxville, TN 37921



#### LIMITED WARRANTY

James Duff Inc. warrants our products to the original purchaser to be free from defects in materials and workmanship. Warranty periods begin at the date of purchase and varies by product. Shocks have a limited lifetime warranty. Headers, Radiators and Suspension Products have a one year warranty. Power Brake Boosters and Master Cylinders have a three year warranty. Adapters and soft goods such as Canvas tops, upholstery, vinyl and rubber products have a 90 day warranty. All warranties are to the original purchaser with proof of purchase only. Such obligations under this warranty shall be limited to the repair or replacement, at JDI's discretion, of any assembly or part which upon examination by JDI proves to be defective. Any costs of removal, installation, reinstallation or freight charges are expressly excluded from this warranty. This warranty covers only manufacturers defects, and does not cover product finish or damage resulting from abuse, misuse, negligence, racing, alteration, accident or damage in transit.

All returns must be pre-authorized by JDEI and accompanied with a Return Goods Authorization Number (RGA) and a dated proof of purchase. Returns must be made within 90 days of purchase, shipped prepaid, packaged in original cartons to prevent damage in shipment and sent to JDI, 3231 NW Park Dr., Knoxville, TN 37921 Returns without an RGA# will be refused.

This warranty is expressly in lieu of all other warranties, expressed or implied, including the implied warranties of merchantability and fitness for use. This warranty gives you specific legal rights including other rights that vary from state to state. Some states do not allow limitations on how long an implied warranty lasts, or do not allow the exclusion of limitation of incidental or consequential damages, so the above limitations and/or exclusions may not apply to you.